



The project: Painting visible masonry

Applying a coat finish to visible masonry, such as lime-sand brick or other brickwork, provides additional protection against moisture caused by the elements. Silicate dispersion or silicone resin façade paints are suitable for such structures. A suitable primer also needs to be applied, depending on the condition of the surface. An appropriate deep sealer should be used if the masonry is absorptive; a primer paint should be applied as an adhesion promoter if the surface is non-absorptive.

The optimum KRAUTOL system solution:



WP-UNI

Opaque, adhesion-promoting primer paint



ULTRA MAXX Complete

The 5-in-1 all-inclusive solution for façades



KRAUTOL®

PROFESSIONAL

This is how it works: an optimum result in a few steps



Preparation and cleaning

Clean the façade with a pressure washer and completely remove any dirt or stains.

Leave façade to dry out completely after cleaning, so the subsequent primer can penetrate the façade more effectively.



Primer

Prime the façade with **WP-UNI**. This primer forms a bonding course between the surface and the subsequent coat of paint. It also ensures that the façade paint dries uniformly and adheres reliably.

Allow façade to dry thoroughly again after priming.



Prime and finish coat

Pre-treat the façade with **Ultra Maxx Complete** (diluted with a maximum of 10% water). The low viscosity of the paint ensures good penetration behaviour, thus achieving effective adhesion in the final coat.

Leave primer coat to dry out thoroughly. Then apply undiluted **Ultra Maxx Complete** façade paint.



Other façade projects

Simply scan the QR code with your smartphone or tablet and access additional information.

12/2017

Systematic façade protection